

Wiring diagram 2nd version

82-780

- Electronic interval rewiper backdoor

- Wiper motor, backdoor
 Washer pump, backdoor
 Detent switch wiper motor backdoor
 Detent switch interval wiper, backdoor
 Detent switch dome lamp rear
- Tipping switch washer pump, backdoor 8-point line connector above backdoor
- Fuse terminal 15

To dome lamp rear

- Main ground behind instrument cluster Ground, luggage compartment wheelhouse right Ground, backdoor (8-point line connector) M2 M8 M9